




# HOW TO FIT



## Sizing Belt

- 1 Detach pull handles off soft panel surface starting point.
- 2 Open clamp on each side and detach panels by pulling up and away from hook surface.
- 3 Set adjustment indicator window over desired size, fold neatly and press down firmly.
- 4 Place belt panels back in clamp and press down firmly.
- 5 Place handles back on soft panel surface starting point.
- 6 Pull ends in opposite directions to reset locking mechanism.

### TLSO W/DLK Placement and Adjustment

Your caregiver should have already adjusted the DLK and the position of the front panel specifically to your body.

- 7 Open the strap on the DLK closed on the left side only, slip your left arm through the loop of the DLK so that the strap rests on your shoulder and the Front Plastic Panel is against your abdomen. Position brace around your back, with back plastic panel centered on your spine and the curve on back panel directly over your spinal curvature. Loosely attach corset with the right soft belt panel over the left panel.
- 8 Snap the right strap of the DLK into the buckle. Re-Attach right soft belt panel with hook interface over left panel snug and press down firmly.
- 9 Pull ergonomic handles, outward to achieve desired compression and fasten onto front soft panel (With desired compression, pull handles end up near midline).
- 10 Pull the shoulder straps on the DLK simultaneously to achieve the appropriate amount of tension, as originally directed by your caregiver.

### TLSO W/ATE Placement and Adjustment

Start with the Venum Hybrid TLSO corset open and the strap on the Thoracic Attachment closed on the right side only.

Your caregiver should have already adjusted the Thoracic Attachment and the position of the right front floating panel specifically to the appropriate settings for your body.

- 11 Slip your right arm through the strap opening of the Thoracic Attachment so that the strap rests on your shoulder and the right front floating panel is against your abdomen as shown in Figure 7. With the posterior plastic panel centered on your back, attach the Venum Hybrid corset. Hold the left abdominal flap firmly with the left hand over the abdomen. Grasp the right flap with the right hand and stretch the flap outwards. Next, wrap the left flap around the body using the Velcro ends to secure the right flap over the left flap.
- 12 Snap the left strap of the Thoracic Attachment into the buckle
- 13 Pull ergonomic handles, outward to achieve desired compression and fasten onto front soft panel (With desired compression, pull handles end up near midline).
- 14 Remove reel from pull handle pocket, and decrease or increase length by reeling cable in or out, respectively.

Warranty: OPTEC USA products are warranted for free repair or replacement due to manufacturer's defects within 90 days of the date of purchase or the date fitted.

SIZE	WAIST MEASUREMENT	SIZE	WAIST MEASUREMENT
PANEL FULLY CLOSED:			
XS:	24" – 26"	XS/S:	26" – 28"
S:	28" – 30"	S/M:	30" – 32"
M:	32" – 34"	M/L:	34" – 36"
L:	36" – 48"	L/XL:	38" – 40"
XL:	40" – 42"	XL/2XL:	42" – 44"
2XL:	44" – 46"	2XL/3XL:	46" – 48"
3XL:	48" – 50"	3XL/4XL:	50" – 52"
4XL:	52" – 54"	4XL/5XL:	54" – 56"
5XL:	56" – 58"		
PANEL FULLY OPEN:			
	57" – 63"		
ADD EXTENDER PANEL:			
	63" – 73"		

